



S 800

KOLAT

TOGO MOTORCYCLE

NO.	Maintenance item	Kilomet number of the maintenace cycle							Remarks
		1000KM	7000KM	14000KM	21000KM	28000KM	35000KM	42000KM	
1	fuel system	Check up	Check up	Check up	Check up	Check up	Check up	Check up	Adjust if necessary
2	Manipulating the lasso	Check up	Check/Adjust	Impediment / adjustment	Check/Adjust	Check/Adjust	Impediment / adjustment	Check/Adjust	
*3	Electric spray system	Check/Adjust	Impediment / adjustment	Check/Adjust	Impediment / adjustment	Impediment / adjustment	Check/Adjust	Impediment / adjustment	Adjustment by professionals
4	Fuel oil filter	The examination of oneself	The examination of oneself	The examination of oneself	Check up	Check up	The examination of oneself	Check up	Replace the original spare parts if necessary
5	Air filter elements	Adjust	Adjust	Adjust	Adjust	Adjust	Adjust	Adjust	Replace the original spare parts if necessary
6	Spark plug gap	Check/Adjust	Check/Adjust	Check/Adjust	Check/Adjust	Check/Adjust	Check/Adjust	Check/Adjust	Adjustment by professionals
*7	Valve clearance	The examination of oneself	Check up	The examination of oneself	Check up	The examination of oneself	Check up	Check from	Adjustment by professionals
8	Engine lubricating oil	Renewal	Renewal	Renewal	Renewal	Renewal	Renewal	Renewal	
*9	Lubricating oil purifier	Wash		Wash	Clean ash	Wash	Wash	Wash	Replace the original spare parts if necessary
*10	Timing chain	The examination of oneself	The examination of oneself	Check up	The examination of oneself	The examination of oneself	The examination of oneself	The examination of oneself	Adjust if necessary
*11	Idling	The examination of oneself	The examination of oneself	Check up	The examination of oneself	The examination of oneself	Check up	The examination of oneself	Adjust if necessary
12	Chain	Check for every 2000KM							

Note : When driving in areas with abnormally wet or dusty areas. the maintenace interval be appropriately shortened. Items marked with * can only be adjusted by professionals.

NO.	Maintenance item	Kilomet number of the maintenace cycle							Remarks
		1000KM	7000KM	14000KM	21000KM	28000KM	35000KM	42000KM	
13	Storage battery	Check up	The examination of oneself	Check up	Check up	Check up	Check up	Check up	Do not for a long time. Should be charged once a month
14	Brake lining	The examination of oneself	The examination of oneself	Check up	Check up	Check up	Check up	Check up	The thicknees of the friction area shall nit be less than 2mm
*15	Brake assembly	Check the interface	Check up	Check up	Check up	Check up	The examination of oneself	Check up	
16	The brake ligt is beautiful	The examination of oneself	Check whether	Check up	Check up	Check up	Check up	Check up	
17	Lighting system	The examination of oneself	Check up	Check up	Check up	The examination of oneself	The examination of oneself	Check up	
*18	Clutch	The examination of oneself	The examination of oneself	The examination of oneself	Check up	The examination of oneself	The examination of oneself	The examination of oneself	
*19	Shock absorber	Check up	Check up	The examination of oneself	Check up	Check up	Check up	Check from	
20	Bolt / nut	Adjust	Adjust	Adjust	Adjust	Adjust	Adjust	Adjust	Critical bolt adjustment torque
21	Front and rear tires	Check up	Check up	Check up	Check up	Check up	Check up	Check from	
22	Direction pressure bear ing	Impediment / adjutment	Check /adjust	Impediment / adjutment	Check /adjust	Check /adjust	Impediment / adjutment	Impediment / adjutment	Adjust by professionals when necessary
23	Coolant liquid	Impediment / adjutment	Impediment / adjutment	Impediment / adjutment	Check /adjust	Check /adjust	Impediment / adjutment	Check /adjust	

Note : When driving in areas with abnormally wet or dusty areas. the maintenace interval be appropriately shortened. Items marked with * can only be adjusted by professionals.